





Important:

- Unpack the units carefully ensuring not to scratch them with the knife blade. Inspect every item carefully before installation as no claim for faults or damages will be accepted once the item is installed.
- We recommend that you use protection (for example a blanket) to cover the working area. Mirrors and worktops are very fragile, we recommend that you put them on battens (and never directly
- Our furniture is designed to be fitted on a level, flat finished wall.
 It is imperative that you use a sanitary grade silicone sealant at the back and sides of every worktop as water infiltrations will damage your unit and this is not covered under our product guarantee.
- All surfaces of all units should not be exposed to standing water or persistent humidity. They must be wiped and dried off immediately after use. If your unit is not cared for correctly it will deteriorate and
- this will not be covered under our product guarantee.

 All our units are guaranteed for 10 years* from date of invoice (1 year for mirrors, electrical items, cisterns, WC frames, sanitary ware, taps and accessories) against all manufacturing defects acknowledged by our company, limited to domestic users.
- The guarantee does not apply to any products that have been misused or abused in any way. The products must be installed and cared for in line with our fitting instructions, local water byelaws, IEE electrical directives and any other applicable regulations.
- In the unlikely event that the product fails within 10 years* (1 year for mirrors, electrical items, cisterns, WC frames, sanitary ware, taps and accessories), we offer a free of charge replacement part (or nearest equivalent). Liability is limited to individual products and does not cover consequential loss/ damage or any further unfitting/refitting costs or financial compensation. The customer will be required to pay for the installation cost of the replacement part.

* Upon completion and registration of the enclosed Guarantee card, refer to general terms of sale


MAINTENANCE:


- Wipe and rinse the surface of the furniture after contact with any chemical product.
- Do not use abrasive cream (cif, etc...), wire wool, scouring pad, solvent, acid, etc...
- Dry the surface off with a soft cloth after cleaning
 For mirrors, use a chamois leather, and dry the edges with a suitable soft cloth.
- Use a dry cloth to clean any electric components, they must be switched off
- OUR FURNITURE WILL DETERIORATE THROUGH EXCESSIVE WATER SPILLAGE OR HEAVY CONDENSATION. IT IS ADVISED THAT EVERY BATHROOM SHOULD BE WELL VENTILATED AND FITTED WITH A SUITABLE EXTRACTOR FAN TO AVOID ANY PERSISTENT HUMIDITY AND ALL FURNITURE SHOULD BE PROTECTED WITH BATH/SHOWER SCREEN ENCLOSURES TO PRESERVE THEIR QUALITY.

ELECTRICAL INSTALLATION:

All Ambiance Bain units fitted with electrical components (mirrors, mirrored cabinets, sockets, etc...) must only be installed in ZONE 3. Installation and fitting of all electrical items must be completed by a qualified electrician. Any final decisions regarding the installation should also be made by the electrician. All electrical items must be tested prior to installation, as liability is limited to replacement items only.

All information is downloadable from the website www.ambiancebain.co.uk








INSTALLATION MEARLE RAS 2002 A VACA

INSTALLATION OF BASIN UNIT



FIX THE WALL PLATES «0008» (screws and wall plugs not included)





1Determine the finished height

Position the wall plate, mark and drill


3Fix the first wall plate

Place the second wall plate aligning it with the first one





All dimensions are in mm.
The dimensions are given to the bottom of the wall plate.







CAUTION:

Ensure that you use the correct fixing according to the type of wall construction.

REMOVE THE DRAWERS, SEE SEPARATE INSTRUCTIONS ATTACHED





CAUTION:

Use wedges to put the unit on the floor


INSTALLATION OF BASIN UNIT




LOOSEN THE WALL HANGING **BRACKETS ON THE UNIT**



HANG THE UNITS ONTO THE WALL PLATES










MARK THE FIXING BRACKETS



Adjust the level of the unit

Mark the holes of the additional support brackets 3 Remove the unit

Drill the holes (screws and wall plug not provided)




CAUTION:

Ensure that you use the correct fixing according to the type of wall construction.





FIX THE UNIT ONTO THE WALL








2/3





4



Hang the unit onto the wall plates

Tighten the brackets on the unit so that the furniture fits to the wall and adjust the levels

Fix the additional support to the wall (screw and wall plug not provided)






<u>CAUTION:</u> Tighten only by hand

Do not forget the seals

a


APPLY SILICONE ON TOP AND SIDE OF UNIT



10.

INSTALL THE CERMAIC TOP ON THE UNIT







11

FIT THE WALL HANGING BRACKET COVERS « 0003 AND 0004 »



INSTALLATION OF BASIN UNIT



CONNECT THE PLUMBING, CHECK FOR LEAKS

Insert the drain (slotted waste) in the hole Not supplied with unit

waste

The connection and elements used are given as an example.



<u>CAUTION:</u> Tighten only by hand Do not forget the seals



FIX THE HANDLES





FIT AND ADJUST THE DRAWER, (SEE SEPARATE INSTRUCTION ATTACHED)



Make sure the unit is level so that the adjustment is not too difficult